

Standard of MIDI

MIDI Standard of JVC Keyboard

Model	Message		Transmission	Receiving
KB-600	Channel 1		Note ON/OFF (Right of Split)	Note ON/OFF
	System Message		Rhythm Start/Stop	Rhythm Start/Stop
			Timing Clock (Tempo)	Timing Clock (Tempo)
KB-800 KB-808	Channel 1	Control change	Note ON/OFF (Right of Split)	Note ON/OFF (Right of Split)
			Sustain ON/OFF	Sustain ON/OFF
			Bend ON/OFF	Bend ON/OFF
			Fill-in ON/OFF	Fill-in ON/OFF
	Channel 2		Note ON/OFF (Left of Split)	Note ON/OFF (Left of Split) (Accomp.)
	Channel 14		--	Note ON/OFF (Arpeggio)
	Channel 15		--	Note ON/OFF (Bass)
	Channel 16		--	Note ON/OFF (Rhythm Accomp.)
	System Message		Rhythm Start/Stop	Rhythm Start/Stop
			Timing Clock (Tempo)	Timing Clock (Tempo)
NS-50	Channel 1	Control change	Note ON/OFF (Upper)	Note ON/OFF (Upper)
			Sustain ON/OFF (Upper)	Sustain ON/OFF (Upper)
			Bend ON/OFF (Upper/Solo)	Bend ON/OFF (Upper/Solo)
			Fill-in ON/OFF (Rhythm)	Fill-in ON/OFF (Rhythm)
	Channel 2		Note ON/OFF (Lower)	Note ON/OFF (Lower)
	Control change		Sustain ON/OFF (Lower)	Sustain ON/OFF (Lower)
	Channel 14		--	Note ON/OFF (Arpeggio)
	Channel 15		Note ON/OFF (Bass)	Note ON/OFF (Bass)
	Channel 16		--	Note ON/OFF (Rhythm Accomp.)
	System Message		Rhythm Start/Stop	Rhythm Start/Stop
Timing Clock (Tempo)			Timing Clock (Tempo)	
NS-70	Channel 1	Control change	Note ON/OFF (Upper)	Note ON/OFF (Upper)
			Sustain ON/OFF (Upper)	Sustain ON/OFF (Upper)
			Bend ON/OFF (Upper/Solo)	Bend ON/OFF (Upper/Solo)
			Fill-in ON/OFF (Rhythm)	Fill-in ON/OFF (Rhythm)
	Velocity		Key touch (Upper)	Key touch (Upper)
	System Ex.		Organ Drawbar	Organ Drawbar
	Channel 2		Note ON/OFF (Lower)	Note ON/OFF (Lower)
	Control change		Sustain ON/OFF (Lower)	Sustain ON/OFF (Lower)
	Velocity		Key touch (Lower)	Key touch (Lower)
	Channel 14		--	Note ON/OFF (Arpeggio)
	Velocity		--	Key touch (Arpeggio)
	Channel 15		Note ON/OFF (Bass)	Note ON/OFF (Bass)
	Control change		Sustain ON/OFF (Bass)	Sustain ON/OFF (Bass)
	Velocity		Key touch (Bass)	Key touch (Bass)
	Channel 16		--	Manual Drums
	System Message		Rhythm Start/Stop	Rhythm Start/Stop
Timing Clock (Tempo)			Timing Clock (Tempo)	
NS-T90	Channel 1		--	Note ON/OFF (Upper)
	Control change	--	Sustain ON/OFF (Upper)	
		--	Tremolo ON/OFF (Upper)	
		--	Chorus ON/OFF (Upper)	
		--	--	
	System Ex.		Organ Drawbar, Regi. Memory	Organ Drawbar, Regi. Memory
	Channel 2		--	Note ON/OFF (Lower)
	Control change	--	Sustain ON/OFF (Lower)	
		--	Tremolo ON/OFF (Lower)	
		--	Chorus ON/OFF (Lower)	
System Ex.		Organ Drawbar, Regi. Memory	Organ Drawbar, Regi. Memory	